


## PM50 - Acrylic Platter Mat

The Fluance Acrylic Platter Mat will improve natural vibration absorption and damp unwanted resonances for a tighter bass response, richer midrange, and improved signal clarity.



### DIRECTIONS

Ensure the turntable's platter is not spinning and remove any other platter mat. Place the acrylic mat, with the recessed center facing upwards, directly on the spindle and lower gently onto the platter.

### CLEANING

The platter mat can be cleaned with a microfiber cloth to remove dust. To remove fingerprints, use warm water with a small amount of mild soap. Ensure the platter mat is completely dry before use.

### SPECIFICATIONS

<b>Material</b> – Acrylic	<b>Height</b> – 0.12" (3 mm)
<b>Diameter</b> – 11.75" (298.45 mm)	<b>Weight</b> – 0.55 lbs (250 g)

Thank you for your purchase of this Fluance® product. We hope you enjoy your experience.  
Questions? Give us a chance to help, we're just a click away.



[Fluance.com/resources](https://fluance.com/resources)



[Fluance.com/support](https://fluance.com/support)



[Fluance.com/videos](https://fluance.com/videos)



[Fluance.com/contact](https://fluance.com/contact)